

# **Shepherd's Envy Pole**

No Trees? No Problem! With our **Shepherd's Envy Pole**, you can hang bird feeders, plants, wind chimes and more anywhere in your yard!

#### Installation:

# Auger

Place the extensions on the three legs of the auger. In a flat area of your yard, hold the
auger erect with the auger tip on the ground. Turn the auger clockwise by the
extension legs, using them as levers to screw the auger into the ground. Be sure to
keep the auger perpendicular to the ground. Turn until the extension legs are flush with
the ground and the installation is stable.

## Pole

- Insert Red Pole Shims into each grooved/swaged end of pole sections (new products will already have these installed).
- There are three identical poles: insert the opened end of first pole into the auger. Connect the additional poles by inserting the opened end of the second pole into the grooved/swaged end of the pole installed in the auger. Insert the opened end of the third pole into the grooved/swaged end of the second pole.
- Tighten the thumb screw in the auger stem to keep the pole in place.

## Single Arm Mount

• Insert the Hanger Arm opened end into the top grooved/swaged end pole that is assembled onto the auger.

#### Last Step

• The stability of your pole and auger will depend in part on the composition of your soil. If installed on a slope or on irregular ground, shim the extension legs with a rock or a piece of wood to make the poles stand straight.