



Seed Saver® Feeder (X-1)

Droll Yankees Feeders can be disassembled for easy cleaning and part replacement.

Cleaning: Please for the sake of the birds, keep your feeders clean! Dirty feeders can harm the birds. Use a mild soap & water solution and a soft brush for thorough, simple cleaning. Dry completely before filling with seed, fruit, mealworms or suet.

Disassemble

1. Turn the dish counter-clockwise (viewed from the bottom) to remove the threaded end of the brass rod from the metal insert located in the center of the dish.
2. Release the collar & set screw by turning the set screw counter-clockwise and remove by sliding the collar & set screw down the brass rod.
3. Slide the dome down the brass rod and remove. The o-ring may be left on the brass rod.

Assemble

1. Install the o-ring, if the o-ring was removed, approximately 1" below the open hook on the brass rod.
2. Slide the dome up the brass rod to the o-ring.
3. Install the collar & set screw by sliding the collar & set screw up the brass rod against the dome, and tighten the set screw.
4. Insert the threaded end of the brass rod into the metal insert, which is located in the center of the dish, and turn the dish clockwise (viewed from the bottom) until secure.
5. The dome may be lowered to the desired height by adjusting the collar & set screw on the brass rod.

Note: The o-ring should always be positioned against the top of the dome and will not allow water to drip down the brass rod into the dish.

